

HoopMaster™ Home Edition Instructions

INCLUDES:

1 Home Edition Station

2 Backing Holder Blocks

1 Hoop Holding Bracket

FOR A FULL YOUTUBE TUTORIAL SCAN HERE

Or visit our YouTube Channel @HoopMaster-MightyHoop




HOME EDITION STATION

- The Station provides multiple hooping positions for a variety of garment types and sizes.
- Letters and numbers allow for consistent, repeatable placement. No need to measure and mark every garment.

BACKING HOLDER BLOCKS

- Magnetically holds backing material.
- 2 included with the Station.



Your choice of one Hoop Holding Bracket included with the Station.

PC-8500

Hoop Holding Bracket




INNOV-IS

Hoop Holding Bracket



SE-PE

Hoop Holding Bracket



ULT

Hoop Holding Bracket



Join Our Socials
Scan the QR Code
or visit hoopmaster.com/links

30 Day Money Back Guarantee
3 Year Limited Warranty
Midwest Products, Inc.
(262) 257- 0930 - hoopmaster.com

Made in the USA

Patented
HM Home Edition (10/23/25)

Left Chest 5x6 Inch Hoop Example

Figure 1




Figure 2




Figure 3




Figure 4



Step 1:

1. Place the Home Edition Station on a table.
2. Attach your hoop to the Hoop Holding Bracket before placing it onto the Station. This will make it easier to align your hoop.
 - For PC-8500: Slide the hoop straight onto the bracket, just like loading it onto your machine.
 - For Innov-is and ULT: As shown in Figure 1, position the hoop at an angle, then lower it into place.
 - Do not force the hoop. If it doesn't slide in easily, it's not aligned correctly.

3. Center the hoop over the intersection of J and 3 as a starting point. See Figure 2.

4. Once in place, open the black magnetic flap on the bracket. Using the site holes, find the closest holes that keep the hoop centered over J and 3. Insert the pins into the Station.

5. Mark your first garment to check the placement. Adjust as needed to achieve the best design location.

Step 2:

1. Place the two Backing Holder Blocks onto the Station.
2. Open the black magnetic flaps and place your backing material over your hoop.
3. Make sure your stabilizer covers the entire hoop for an even, smooth hooping.
4. Close the magnetic flaps to secure your backing in place while hooping. Your setup should look like Figure 3.

Step 3:

1. Pull your garment over the Station.
2. Make sure the shoulder seams are even on both sides of the Station to ensure the garment is straight.
3. Align the inner ring with the hoop.
4. Check that your logo location mark is centered within the hoop. If it's not centered, adjust the bracket position or reposition the shirt on the Station until it's in the correct place. See Figure 4 for the final left chest placement.



Join Our Socials
Scan the QR Code
or visit hoopmaster.com/links

30 Day Money Back Guarantee
3 Year Limited Warranty
Midwest Products, Inc.
(262) 257- 0930 - hoopmaster.com

Made in the USA

Patented
HM Home Edition (10/23/25)

Figure 5



Set-Up and Hoop Removal

Always note the letter where the collar of the shirt is pulled down to.

- As you can see in Figure 5, the collar is pulled down to C.
- This determines the height of the design in the hoop.
- If you are hooping multiple garments of the same style and size, write down the bracket location, hoop size, and placement position for future reference.

When removing the shirt from the Station:

- For PC-8500 hoops, lift the hoop straight up.
- For Innov-is and ULT hoops, lift the front of the hoop first.



Hooping Youth Shirts/Onesies

- Use the slots on the Station top to pull the garment onto the Station.
- Center the hoop horizontally on the Station.
- Place the Hoop Holding Bracket at the bottom of the Station.
- Position one Backing Holder Bracket at the top of the Station to hold the backing material in place.
- Smooth the garment and check alignment before hooping.



Hooping Sleeves

- Use the smallest slot on the Station to pull the sleeve onto the Station.
- Use the Hoop Holding Bracket to hold your backing material in place.
- Align the hoop so the design area is flat and straight on the sleeve.

Note: The methods used to hoop large and small items are almost identical.

**Scan the QR Code for
Video Instructions**



Join Our Socials
Scan the QR Code
or visit hoopmaster.com/links

30 Day Money Back Guarantee
3 Year Limited Warranty
Midwest Products, Inc.
(262) 257- 0930 - hoopmaster.com

Made in the USA

Patented
HM Home Edition (10/23/25)